


PARTS PROCESSING



LOAD

PENETRANT

DWELL 1

DWELL 2

PRE-RINSE

EMULSIFIER

POST-RINSE

DRYER POSITION 1 DRYER POSITION 2

90° TURN

DEVELOPER

UNLOAD






LINE OPERATION

- HMI controls part basket through line
- Track, record, and process data
- Run, motion control according to recipe input from operator
- Infrastructure PLC



LOCKTIME PRO+ LOCKTIME PRO+ 00:52 00:00 00:00 00:52 1/1 Line Dwell 2 Line Dwell 1 **Load Dwell** Penetrant Dip Dryer 2 Dryer 1 PostRinse/To Emulsifier PreRinse uchUp Scan necessary information, and track data for auditing purposes 4 'ium'






LOCKTIME PRO+

- Scan part baskets into system
- LOCKTIME PRO+ keeps track of baskets in process, and all process specific data






LOCKTIME PRO+

- Recipe scanning collects data for all processes
- LOCKTIME PRO+ logs data for review at a later date
- Produce detailed reports on any previous basket run
- Green indicates a healthy process
- Red indicates process failure





Press System ON button on Infrastructure Panel



PanelView 5510



RECIPE

- With LOCKTIME PRO+ screen up, scan parts into system (Scanner is setup to connect with LOCKTIME PRO+ unit
- Scan multiple parts, recipes are verified
- Scan basket, press Initiate Basket on HMI screen





RECIPE

- Initiate LOCKTIME PRO+
- Scan multiple parts, recipes are verified
- In operator mode, the whole process can be performed
- Edit recipes in admin mode to change: penetrant dip time, penetrant dwell time, recycle rinse passes, freshwater rinse passes, emulsifier dip time etc.
- Operator intervention stations allow for the necessary process inspections






RECIPE TRACKING

- Initiate LOCKTIME PRO+
- Scan Recipe #, Serial #, Service Order #
- Scan basket, press Initiate Basket









LOAD

- Adjustable basket features accommodate a variety of parts
- Physically push basket into Penetrant Dip Station to engage processing (an alarm will sound if basket is not properly engaged)
- Remove empty cart, and bring to Unload Station
- Operator safety ensured with area light curtain










PENETRANT DIP

- Use Infrastructure Panel to monitor and edit penetrant levels
- Tank high level alarm and pump will prevent any unwanted spills and cleanup





LINE DWELL rez o + > f & LOCKTIME System Overview Infrastructure PRO+ Station 500 Station 100 Station 200 Station 300 Station 301 Station 400 **Emulsifier Dip** Line Dwell Pre-Rinse Load Penetrant Dip Line Dwell Dip Time (mm.ss) Recycle Cart Docked 0 0.00 0.00 Passses Setpoint Remaining Current Recipe Setpoint Remaining Setpoint Remaining Setpoint Remaining Fresh 0 14.15 20.00 5.15 Passses 0.00 0.00 20.00 0.00 0.00 Rinse Dip Time (mm.ss) Dwell Time (mm.ss) Dwell Time (mm.ss) Dwell Time (mm.ss) Scanned Recipe # Complete 0 1 Recipe: Recipe: Recipe: Recipe: Recipe: Ok To Advance **Empty** Loaded **Empty Empty** Station 600 Station 800 M Station 900 Station 700 Station 701 Station 1000 Post Rinse Dryer Pos 1 Dryer Pos 2 Turn Dry Developer Unload 150.8 °F 150.8 °F Temp Temp Setpoint Remaining Setpoint Remaining 0.00 0.00 0.00 0.00 According to selected recipe, parts rest in dwells for specified time Dwell Time (mm.ss) Dwell Time (mm.ss) Cart Docked

Recipe:

Recipe:







PRE-RINSE


- Set up recipe for operator intervention, or hit Request Access button for manual access when program permits
- Pre-Rinse cycle consists of turntable that spins 360° for thorough rinsing
- Depending on part complexity, recipe can be modified to include one or more rinse cycles
- Calibrated NIST cerfied gauges conveniently shown on front of station





PRE-RINSE

- Request Access button allows operator to manually inspect parts before continuing through process
- UV-A and Visible Light switch allows operator to control Profusion UV-A lamp with white light, and/or station mounted Magnum-GO allows for additional inspection
- To inspect parts in basket 360°, manually use Jog Table switch. When manual inspection is complete, close door, hit Inspection Complete switch, the table will automatically rehome before further conveyance






PRE-RINSE

- Calibrated NIST certified gauges make monitoring temperature and pressure of water in spray header and hand sprayer painless
- Easily removable front panel gives access to certified gauges. Quick connect couplings allow for gauges to be effortlessly removed and replaced









EMULSIFIER Dip tank filled with emulsifier soap solution to clean oil base penetrant off parts




EMULSIFIER

- Emulsifier solution aids in the removal process of oil based penetrant
- To meet the maximum 2-minute dwell time of ASTM-E1417, the control system does not allow the emulsifier treatment until the Post-Rinse Station is empty













POST-RINSE

- Set up recipe to have operator intervention, or hit Request Access button for manual access when the recipe permits
- Post-Rinse Cycle consists of turntable that spins 360° for thorough rinsing
- Depending on part complexity, recipe can be modified to include one or more rinse cycles
- Rinse Cycle ensures thorough rinse with actuated 4-sided spray header and servo controlled turntable





POST-RINSE


- Calibrated NIST certified gauges make monitoring temperature and pressure of water in spray header and hand sprayer painless
- Easily removable front panel gives access to certified gauges. Quick connect couplings allow for gauges to be effortlessly removed and replaced













Infrastructure HMI to turn ON/ Enable Dryer



Nem-Bradley




- Set temperature on Infrastructure Panel Controller
- Thermocouple on Dryer Station





 Thermocouple attached to back of Dryer Station with probe inserted through top of dryer into station





■ Temperature gauge on front of Dryer Station





CALIBRATION

 System sensors are able to be offset/calibrated to a corrected output on the HMI























DRY DEVELOPER

- Recipe can automatically allow access for operator intervention for process verification
- Recipe parameters apply developer for allotted time depending on application demands
- Dust collector is engaged to clear station
- Inspect parts for adequate developer coverage
- Use manual air gun set to 5 PSI max to remove excess developer
- UV-A and Visible lights mounted on booth ceiling
- Recipe set dwell time used within Developer Station














INFRASTRUCTURE OVERVIEW


 Penetrant Tank, Freshwater Tank, Emulsifier Tank, Sump Tank, Dryer, quick overview to show tank levels etc.





PENETRANT TANK

- Admin access required to set Penetrant Tank level and maintenance parameters
- Diaphragm Pump transfers penetrant from 50 gallon drum into Penetrant Dip Tank as needed to meet tank level settings





FRESH WATER TANK

- Freshwater Tank Heaters are controlled by the Infrastructure HMI
- Tank Fill Solenoid Valve maintains the tank level
- Fresh Water Tank feeds the fresh water cycles of the Pre-Rinse and Post-Rinse stations
- Water temperature for rinse process is settable here
- Air agitation ensures consistent temperature reading




Allen-Bradley



EMULSIFIER TANK


- Admin access required to set tank level and maintenance parameters
- Proportioning Pump mixes defined concentration





SUMP TANK

- Admin access required to set tank level and maintenance parameters
- Sump Pump



Nan-Bradilay



DRYER

- Enable Dryer
- Set temperature with control unit integrated into infrastructure panel





MAINTENANCE

 Flow Meter on freshwater tank used to record water usage history





Allem-Bradley



LOCKOUT / TAGOUT

Lockout / Tagout locations







PanelView 5510

SAFETY

 Area guarding and safety light curtains for operator safety throughout process





