

# Spray Can Adapter Mounting Instructions

Remove and discard the two lower screws from the lamp you wish to attach the spray can adapter

Use the included 5/8" long 6-32 screws to attach the adapter to the front of the lamp. \*\*Chase the threads with a 6-32 tap if the screws fail to seat completely\*\*

